



Change to the mode
USER BOX FAX/SCAN COPY TOUCH SCREEN


Adjust brightness of the touch screen

Click to login/logout

Energy saving ON/OFF

Specify panel settings

Switch to Enlarge display mode



Main Power — Main power indicator

Power — **POWER ON/OFF**

Mode Memory — Save copy settings

Utility/Counter — Open Utility/Counter screen

RESET the settings

Interrupt a copy job

STOP a process

Open **HELP** screen

Input a value or a number

CLEAR a value

START a process

Proof a copy set